



ASSEMBLY INSTRUCTION FOR ACME FURNITURE

MODEL# LV02834

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, Identify and count all parts and metal hardware. Compare with all parts listed to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

COMPONENT PARTS		
DESCRIPTION	PART NAME	Q'TY(PCS)
① Seat		1PC
② Backrest		1PC
③Ears(Left&Right)		2 PC

HARDWARE REQUIRED

A: Power Cord



Attention


***Some number parts listed on the instruction sheet may not be in parts bag as they may be assembled. Carefully check parts and packing materials prior to ordering replacements. ***

HOW TO ASSEMBLE:

STEP 1

No.I: Connect the white wire extending from the backrest to the white wire extending from the seat base.


No.II: Wire connect the motor and Power cord (A).



STEP 2

Join sofa by back connector

Insert the Chair back (②) on the Chair seat (①). Gently push down until the back locks into position.




Insert the ears (③) on the Chair back (②), Gently push down until the back locks into position.

STEP 3






Assembly complete

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.




HOW TO USE CONTROL PANEL:

How to recline?



Button function:



- (1) Lock Lock all key functions
- (2) Light Control the LED Light under the seat
(Left & Right Cupholders)
- (3) Up Open the headrest
- (4) Down Close the headrest
- (5) open Recliner
- (6) Close Back to sitting position
- (7) Home Reset Key